

for contacts of insert series:	page
CX 6/36* (40A)	130
CX 12/2* (40A)	131
MIXO (40A)	138÷139

* the underlined polarities indicate those contacts that require the tools shown in this page

**) On request is possible to supply the pneumatic crimping tool version (part. No. CXPZP D), please contact us for further details.

manual crimping tool **)
turret heads
gauge



removal tool



description	part No.	part No.
crimping tool for 40A DANIELS M309 model (turret excluded)	CXPZ D	
turret heads (see note) - for <u>male</u> contacts 40A - for <u>female</u> contacts 40A	CXTP 40 M CXTP 40 F	
"go / no go" control gauge to verify indenter closure (see note)	CXPNP	
removal tool for the extraction of contacts from the inserts - for 40A contacts		CXES

Notes:


Positioning turret

- An interchangeable and indispensable accessory of the CXPZ D crimping tool, it precisely positions the contact where crimping is performed. Each series of contacts (male or female) requires its own turret.


"go / no go" control gauge

- A tool used to periodically check that the crimping tool meets standard requirements.


CXPZ D



CXES



CXPNP



CXTP 40 M and CXTP 40 F

